
19x15w ZOOM WASH MOVING HEAD

**Specification:**

Item name:ELMH-19*15-WASH

Item Input voltage :100–240 V, 50/60 Hz

Lamp: 19pcs 15W RGBW 4in1 LEDs

Power consumption: 350W

Beam angle: 8-58degree

Dimmer: 0-100% dimming Strobe: 0~20HZ

Control mode : Standard DMX512, Automatic and
Master/ slave mode

DMX channel: 16/24CH

IP rate: IP20

Pan rotation:540 degree Tilt rotation:240 degree

Data in/out:3-pin XLR in&out and PowerCon in&out

N.W.:8kgs G.w.:9.5kgs

Dimension:32*21*38cm

1、DMX Settings

This option is used to set the DMX communication address and channel mode. Press “Enter” to enter the setting. Press “UP” to increase the address number. Otherwise, “DOWN” to decrease the address number. After selecting the address, select the address. Press “Enter” to save and exit. The channel has 24 channels and 16 channels mode selection.

2、Run Mode

This option is used to set the working mode of the lamp body. Press “Enter” to enter the setting. Press “UP” or “DOWN” to select the working mode. The working mode has “DMX512”, “Slow” and “Fast”. “”, “Sound” and “manual”, select the working mode and press “Enter” to save and exit.

DMX512: DMX mode

Slow: Auto mode slowly

Fast: Auto mode in fast

Sound sound control mode

manual: manual operate

3、Invert PAN/TILT

This option is to reverse the direction of the X/Y axis. Press “Enter” to enter the setting. Press “UP” or “DOWN” to reverse the selection of the X/Y axis. Select “Yes” to indicate X. /Y axis is reversed. Select “NO” to indicate that the X/Y axis is not reversed. After selecting the direction, press “Enter” to save and exit.

4、Display Set

This option is to set the LCD font backwards, Chinese and English display and backlight of the display panel. Press “Enter” to enter the setting. Press the “UP” or “DOWN” button on the LCD backlight to select the switch. Select “Yes”. ” indicates that the LCD backlight is always on and off, and “NO” means that no button operation is turned off after 20 seconds, and then turned back on when there is a button operation. After selecting the settings, press “Enter” to save and exit.

Invert Word

English/Chinese:

LCD Backlight on

4、Manual Set

This option is to set the parameters of the lamp body scene. Press “Enter” to enter the save and run online. The operating mode (Run Mode) of the pre-conditioner should be set to manual, which is valid only after the power is off. The next time you turn it on, you can restore the previous power-on state.

PAN

PANMICO

TILT

TILTMICO

XY_SPEED
ZOOM
DIM
STROBE
DIM_R0
DIM_G0
DIM_B0
DIM_W0
DIM_R1
DIM_G1
DIM_B1
DIM_W1
DIM_R2
DIM_G2
DIM_B2
DIM_W2
LIGHT_CH
SHOW_SP
MACRO_CH

6、 Sound Sence

This option is to switch the sound sensitivity of the lamp body. Press “Enter” to enter the setting. Press “UP” or “DOWN” to select the sensitivity of 0~100 level. After selecting the sensitivity, press “ Enter” save and exit.

7、 System Set

8、 System Information

The version:V1

PAN Reset: Normal Wrong

TILT Reset: Normal Wrong

Default Settings:

Code Settings:

When the password channel is used, the user needs to transfer the password to view and set the XY fine adjustment and lamp white balance parameters.

The number of passwords is four. Press “UP” or “DOWN” to enter. The factory password is “DOWN DOWN UP UP”.

PAN_INIT:

TILT_INIT:

SET_R:

SET_G:

SET_B:

SET_W:

8、Reset

After the user selects reset, wait for 3 seconds and the lamp will be reset.

24CH	FUNCTION	DMX Value	description
1	X	0-255	0~540 degree
2	X fine	0-255	16bit
3	Y	0-255	0~270 degree
4	Y fine	0-255	16bit
5	XY speed	0-255	0-100%
6	Zoom	0-255	
7	Dimmer	0-255	0 → 100% intensity
8	Strobe	0-3	No function
		4-95	0-100% (1HZ~25HZ)
		96-176	Random strobe
		177-255	Fast strobe
9	R1	0-255	Red 1 dimmer 0-100%
10	G1	0-255	Green 1 dimmer 0-100%
11	B1	0-255	Blue 1 dimmer 0-100%
12	W1	0-255	white 1 dimmer 0-100%
13	R2	0-255	Red 2 dimmer 0-100%
14	G2	0-255	Green 2 dimmer 0-100%
15	B2	0-255	Blue 2 dimmer 0-100%
16	W2	0-255	white 2 dimmer 0-100%
17	R3	0-255	Red 3 dimmer 0-100%
18	G3	0-255	Green 3 dimmer 0-100%
19	B3	0-255	Blue 3 dimmer 0-100%
20	W3	0-255	white 3 dimmer 0-100%
21	function	0-24	Built-in effect 1
		25-492
		50-743
		75-994
		100-1245
		125-1496

		150-1747
		175-1998
		200-2249
		225-25510
22	Function speed	0-255	From fast to slow
23	macro	0-49	
		50-99	Show
		100-149	Auto 1
		150-199	Auto 2
		200-255	Sound control
24	Reset	0-250	No function
		251-255	Reset(wait for 3s)

16CH	Function	DMX Value	description
1	X	0-255	0~540
2	X Fine	0-255	16bit
3	Y	0-255	0~270 degree
4	Y Fine	0-255	16bit
5	XY speed	0-255	From fast to slow
6	Dimmer	0-255	0-100%
7	Strobe	0-3	No function
		4-95	Strobe (1HZ~25HZ)
		96-176	Random strobe
		177-255	Fast strobe
8	R	0-255	Red dimmer 0-100%
9	G	0-255	Green dimmer 0-100%
10	B	0-255	Blue dimmer 0-100%
11	W	0-255	White dimmer 0-100%
12	zoom	0-255	
13	function	0-24	Built-in effect 1
		25-492
		50-743
		75-994
		100-1245
		125-1496
		150-1747
		175-1998

		200-2249
		225-25510
14	Function speed	0-255	From fast to slow
15	macro	0-49	
		50-99	Show
		100-149	Auto 1
		150-199	Auto 2
		200-255	Sound control
16	Reset	0-250	No function
		251-255	Reset(wait for 3s)

Routine maintenance

Cleaning and maintenance

The equipment requires daily cleaning and maintenance. The service life of the equipment depends largely on the operating environment and daily cleaning and maintenance. Please disconnect the power before opening any cover.

The optical components should be lightly rubbed, the surface of the coating is very brittle, and it is easy to scratch. Do not use destructive solvents or damage the plastic or coated surface. Use a soft brush, tissue, air cleaner or pressure blower to remove dust from the fan and air vents.